

Hybri-Gard HTU Application Instructions



Mixing Instructions

- Tools: Use high speed and jiffy mixer paddle, 5 gal bucket



- Clear System

1. Pour part A in a 5 gal bucket.



2. Pour part B in a 5 gal bucket. Mix for 1 minute.



3. Pour part C aluminum oxide into bucket and mix for another minute.



- Pigmented System

1. Pour part B into 5 gal bucket and add 32. oz. of 700 series powder pigment and Mix for 2 minutes on high speed.



2. Pour part A into the part B and pigment and mix for one minute.



3. Pour part C aluminum oxide into bucket and mix for another minute



- Application Instructions

- Tools: 3/8” nap 18” roller frames and covers, roller poles and 18” roller trays.



Always dip and roll this topcoat.

1. Wet your roller.
2. Initially roll left to right or right to left.
3. Back-roll north to south or south to north

Making sure you are not applying it too heavy

4. Then while on foot spikes roll off left to right or right to left again lifting roller on each path while overlapping slightly and making sure you're not leaving spike marks

